

# Wood SERIES

# SUNWALK<sup>®</sup>

## SUPERIOR SURFACES

The look of a traditional wood dock without the maintenance or splinters.

SunWalk<sup>®</sup> **Wood Series** is our dock surface option that incorporates a traditional wood dock plank design aesthetic. Engineered for marine use this tough and beautiful decking will look great for years to come.

We know how you use your dock – boating, swimming, fishing, sunning and relaxing. We designed our surfaces to keep you doing more of those things with less maintenance and repair to your dock! Your leisure time is priceless, work less and enjoy more with SunWalk<sup>®</sup>!

## FEATURE BENEFITS

- **Maintenance Free** – No painting, staining, insects, splinters or rot, just enjoy your dock.
- **Traditional Look** – The look of wood without all the maintenance.
- **Easy Installation** – Larger panel sizes mean less decking time and effort, uses less than half the fasteners of regular deck boards.
- **Cool** – Hot sun won't make your decking too hot to walk on, stay barefoot and comfy.
- **Strength** – Solid underfoot and proven strength in more than a decade of applications.
- **Durability** – UV protected, stiff and impact resistant.
- **Environmental Sensitivity** – 100% recyclable, no chemical pressure treatments that leach into your environment.
- **Quality** – Consistent size, flatness & performance. No curling or cupping like wood.

## PRODUCT SPECIFICATIONS

Product	Length	Width	On Centre	Weight
WSPR-4824	24"	48"	16"	13.5 lbs

Commercial applications require 12" on centre for all product SKU's

SunWalk<sup>®</sup> Stone

SunWalk<sup>®</sup> Cedar

[WWW.SUNWALKDOCKS.COM](http://WWW.SUNWALKDOCKS.COM)

# INSTALLATION GUIDELINES

1. **Sub-Structure** – Proper installation of the SunWalk® panels starts with the substructure. Consult your local builder or engineer to ensure your substructure will comply with your local codes and provide the support and spacing to accept the SunWalk® panels.

2. **Fastening** – Lay your first SunWalk® panel on the substructure, ensuring you have the panel flat and square. Once panel is square to the substructure, fasten the SunWalk® panel using the pre-drilled mounting locations with #10 or #12 pan head fasteners

**Wood fasteners** – #10 or #12-3" pan head wood screws (SS is recommended)



**Metal fasteners** – #10 or #12 – 1.75" pan head self-drilling/tapping (SS is recommended, length may vary to metal thickness)

3. **Alignment** – Lay panels out making sure they stay square to the sub-structure. You can lay 8-10 panels out and then fasten each individually to ensure proper alignment to sub-structure. Repeat steps for further panels.


4. **Spacing** – SunWalk® panels are engineered not to shrink or swell due to changes in moisture, however changes in temperature will cause slight expansion and contractions. We do recommend that 1/32" gapping is used on the long side of the panel and 1/32" is used for the 2' side of the panels, for every 30°F of difference between installation temperature and the hottest temperature expected. In cold climate regions, gapping due to contraction will occur in the exact reverse.

5. **Cutting** – SunWalk® panels maybe required to fit your application, in this case you can cut the SunWalk® panel with a regular wood blade saw. Once panel is cut you will need to support the panel under the cut edges to provide proper support.

## Recommended Expansion Gap Allowance



2'x4' require 16" on centre support



## QUICK TIPS

- **Codes and Standards** – Always conform and or consult your local building codes to ensure you follow proper building guidelines
- **Safety** – Always use proper PPE (Personal Protective Equipment)
- **Fastening** – **Do not overtighten** the fasteners, all you want to do is trap the panel in place, this allows for any expansion and contraction.
- **Need Help?** – For additional information please call us toll free at 1-844-478-6925 or visit us online.

**SUNWALK®**  
SUPERIOR SURFACES



[WWW.SUNWALKDOCKS.COM](http://WWW.SUNWALKDOCKS.COM)



Toll Free: 1-844-478-6925